




Wire to Board Series - Wire to Board Connectors, Straight & Right Angle



3750S-XX

No. Of Positions
S: Straight Type
R: R/A Type

3750X-XX

No. Of Positions
G: W/Lock Housing
C: W/Guide Housing
A: Flat Type Housing

3750 Series:
2.54mm Pocket Header Straight & R/A Type
3750 Series:
2.54mm Pocket Housing Connector

Mating Part:
3750S-XX Mating 3750A-XX



5561A-XX-XX

Blank W/Mounting Ear
01: W/O Mounting Ear
No. Of Positions
Plug Housing Single Row

5560A-XX

No. Of Positions
Receptacle Housing Single Row

5561A Series:
3.0mm Plug Housing Single Row Connector
5560A Series:
3.0mm Receptacle Housing Single Row Connector

Mating Part:
5561A-XX Mating 5560A-XX



5561SA-XX


No. Of Positions
SA: Straight Single Row
RA: R/A Single Row

5560A-XX

No. Of Positions
Receptacle Housing Single Row

5561 Series:
3.0mm Plug Straight & R/A Single Row Connector
5560A Series:
3.0mm Receptacle Housing Single Row Connector

Mating Part:
5561SA-XX Mating 5560A-XX



5561-XX

No. Of Positions
Plug Housing Double Rows

5560-XX

No. Of Positions
Receptacle Housing Double Rows

5561 Series:
3.0mm Plug Housing Double Rows Connector
5560 Series:
3.0mm Receptacle Housing Double Rows Connector

Mating Part:
5561-XX Mating 5560-XX

2000 Arctic Ave, Bohemia, NY, 11716
Tel: 1-800-346-3532

UNIT:mm